

CHEVROLET P1A88: 42 VOLT SYSTEM PERFORMANCE

OVERVIEW

Severity	:	Medium
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$80-\$150
Can I Still Drive?	:	Yes (Short-term only)

What Does The Chevrolet P1A88 Code Mean?

Ignition voltage is 7 V and no more than 16 V. The accessory DC power control module runs a portion of the diagnostics for this DTC at Accessory/Ignition On. The accessory DC power control module runs additional diagnostics when the 42 volt output is commanded on.

- An external condition has caused an accessory DC power control module 42 volt malfunction,
- The accessory DC power control module has detected an internal malfunction.

Reference Sources

[Chevrolet P1A88](#), DTCDECODE.