

CHRYSLER B1442: VES MENU INPUT BUTTON STUCK

OVERVIEW

Severity	:	Low
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$50-\$100
Can I Still Drive?	:	Yes

What Does The Chrysler B1442 Code Mean?

The DVD Player detects a closed switch for 60 seconds.

What Are The Potential Causes Of The Chrysler B1442 Code?

Dvd Player

Reference Sources

[Chrysler B1442](#), DTCDECODE.