

CHRYSLER B1828: TRUNK/GATE RELEASE CONTROL CIRCUIT

OVERVIEW

Severity	:	Medium
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$100-\$400
Can I Still Drive?	:	Yes

What Does The Chrysler B1828 Code Mean?

Continuously When the Cluster senses a low or open condition on the (P31) Decklid/Liftgate Release Driver circuit during a release command for over 10 seconds, this code will set.

What Are The Potential Causes Of The Chrysler B1828 Code?

- (P31) DECKLID/LIFTGATE RELEASE DRIVER CIRCUIT SHORT TO GROUND
- (P31) DECKLIS/LIFTGATE RELEASE DRIVER CIRCUIT SHORT TO VOLTAGE
- (P31) DECKLIS/LIFTGATE RELEASE DRIVER CIRCUIT OPEN
- DECKLID OR LIFTGATE LATCH
- INSTRUMENT CLUSTER

Reference Sources

[Chrysler B1828](#), DTCDECODE.