

CHRYSLER B1A6B: STEERING COLUMN LOCK MODULE NOT INITIALIZED

OVERVIEW

Severity	:	Medium
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$100-\$900
Can I Still Drive?	:	Yes

What Does The Chrysler B1A6B Code Mean?

The Wireless Ignition Node (WIN) detects that the Steering Column Lock Module has not initialized. The WIN has been enabled with the Steering Wheel Lock Module but did not personalized.

What Are The Potential Causes Of The Chrysler B1A6B Code?

- Steering column lock module not initialized
- Steering column lock module (ELV)

Reference Sources

[Chrysler B1A6B](#), DTCDECODE.