

CHRYSLER B232A: RAIN SENSOR OPTICAL PATH 2 PERFORMANCE

OVERVIEW

Severity :  Medium

DIY Difficulty Level :  Intermediate

Repair Cost : \$50-\$200

Can I Still Drive? : Yes

What Does The Chrysler B232A Code Mean?

Each optical track (received value) is monitored once a second while the rain sensor is active (WK Intermittent 1-5, LX intermittent 1-6) and compared to a small value. The optical track value must be below this value for 4 minutes (checked once per second) before this DTC will be set. Once the DTC is set, the optical track must be above the threshold for 4 minutes (checked once per second) before the DTC is cleared.

What Are The Potential Causes Of The Chrysler B232A Code?

Rain sensing module

Reference Sources

[Chrysler B232A, DTCDECODE.](#)