

FORD P1012: WASTEGATE CONTROL PRESSURE SENSOR CIRCUIT LOW

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$150-\$500
Can I Still Drive?	:	Yes (Short-term only)

What Does The Ford P1012 Code Mean?

This DTC sets when the wastegate vacuum sensor reading is less than a calibrated threshold and the fault timer has exceeded the calibrated time threshold indicating a short to SIGRTN or ground.

What Are The Potential Causes Of The Ford P1012 Code?

- WVS circuit short to ground
- Damaged wastegate vacuum sensor

Reference Sources

[Ford P1012](#), DTCDECODE.