

What Does The Ford P111B Code Mean?

This DTC sets when the engine coolant temperature does not rise by a calibrated threshold value when compared to the inferred engine coolant temperature.

What Are The Potential Causes Of The Ford P111B Code?

- Low engine coolant
- Damaged heater core shut off valve
- Damaged coolant bypass valve
- Damaged ECT sensor

Reference Sources

<u>2016 Powertrain Control Emissions Diagnosis On Board Diagnosis</u> - Sections 4: Powertrain DTC Charts and Descriptions, P111B, page 143.

