

FORD P1335: EXHAUST GAS RECIRCULATION (EGR) POSITION SENSOR MINIMUM/MAXIMUM STOP PERFORMANCE

OVERVIEW

Severity	:	Medium
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$93-\$123
Can I Still Drive?	:	Yes

What Does The Ford P1335 Code Mean?

This error occurs when voltage of the EGR valve falls below the minimum threshold.

What Are The Potential Causes Of The Ford P1335 Code?

- Wiring
- EGR valve assembly
- PCM

Reference Sources

[6.4L Power Stroke® Diesel Engine Overview for 2008 "F" Series Super Duty](#) - 2007 International Truck and Engine Corporation, P1335, page 98.