

FORD P1444: PURGE FLOW SENSOR CIRCUIT LOW INPUT

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$150-\$300
Can I Still Drive?	:	Yes (Short-term only)

What Does The Ford P1444 Code Mean?

Key on or engine running; and the PCM detected the Purge Flow (PF) sensor signal was less than the minimum calibrated limit of 0.40v during the Continuous self test.

What Are The Potential Causes Of The Ford P1444 Code?

- PF sensor signal circuit is shorted to sensor or chassis ground
- PF sensor is damaged or has failed
- PCM has failed

Reference Sources

[Ford P1444](#), DTCDECODE.