

GMC P1832: PRESSURE CONTROL (PC)/SHIFT LOCK SOLENOID CONTROL CIRCUIT HIGH VOLTAGE

OVERVIEW

Severity	:	<div><div></div></div> High
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$150-\$250
Can I Still Drive?	:	No

What Does The GMC P1832 Code Mean?

Conditions for setting this code:

- The engine speed is greater than 500 RPM.
- Ignition voltage is between 8-18 volts.
- High side driver 2 is enabled.
- DTC [P1831](#) has not failed this ignition.

Reference Sources

[GMC P1832](#), DTCDECODE.