

HONDA B1277: HEADLIGHT AUTO POSITION CIRCUIT MALFUNCTION

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	Yes (Short-term only)

What Does The Honda B1277 Code Mean?

A malfunction has been detected in the headlight AUTO position circuit.

NOTE: If you are troubleshooting multiple DTCs, be sure to follow the instructions in B-CAN System Diagnosis Test Mode A.

What Are The Potential Causes Of The Honda B1277 Code?

- "Open" or "Short" between driver's under-dash fuse/relay box and the combination light switch
- Faulty driver's MICU; replace the driver's under-dash fuse/relay box
- Faulty combination light switch

Reference Sources

[Honda B1277](#), DTCDECODE.