

What Does The Honda P1182 Code Mean?

Key on or engine running, and the PCM detected an unexpected low voltage condition on the Fuel Temperature sensor signal circuit.

What Are The Potential Causes Of The Honda P1182 Code?

- Fuel temperature sensor signal circuit is shorted to ground
- Fuel temperature sensor is damaged or has failed
- PCM has failed

Reference Sources

Honda DTC Codes for P1182 - Page 2.

