

## What Does The Honda P1441 Code Mean?

No IAT, MAP or TP sensor codes set, system voltage at 11-16v, ECT and IAT sensor signals more than 41°F, startup ECT sensor signal less than 122°F, key on (prior to engine cranking), and the PCM detected the EVAP Purge Switch indicated 12v (open circuit).

## What Are The Potential Causes Of The Honda P1441 Code?

- Vacuum switch signal circuit is open between switch and PCM
- Vacuum switch ground circuit open between switch and ground
- Vacuum switch is damaged or has failed
- PCM has failed

## **Reference Sources**

- Honda DTC Codes for P1441 Page 5.
- Technical Service Bulletin 00-011 Honda Motor Co., Ltd, 1998-99 Passport

