HONDA P15AC: ENGINE MOUNT CONTROL UNIT INTERNAL CIRCUIT MALFUNCTION OVERVIEW Severity : High DIY Difficulty Level : Advanced Repair Cost : \$120-\$500 Can I Still Drive? : No

What Does The Honda P15AC Code Mean?

With the ignition switch ON, P16C4 and P16C9 are not active. The ACM actuator driving power voltage is 24 V or less for at least 2.6 seconds.

NOTE: Before you troubleshoot, record all freeze data and any on-board snapshots, and review the general troubleshooting information.

What Are The Potential Causes Of The Honda P15AC Code?

- Poor connections or loose terminals at the engine mount control unit and the engine mount actuator
- Faulty engine mount control unit

Reference Sources

Honda DTC Codes for P15AC - Page 8.

