MALFUNCTION)		
		OVERVIEW
Severity	:	High
DIY Difficulty Level	:	Advanced
Repair Cost	:	\$50-\$150
Can I Still Drive?	:	Yes (Short-term only)

What Does The Honda P16D5 Code Mean?

With the ignition switch ON, for 3 seconds and battery voltage at a minimum of 10.0 V, one of the following malfunction conditions exist

- Condition 1: The PCM does not receive any signals via the F-CAN lines for at least 1 second.
- Condition 2: The information sent from the CVT CPU is abnomal at least 20 times.

What Are The Potential Causes Of The Honda P16D5 Code?

- PCM may need to be updated with the latest software
- Faulty PCM

Reference Sources

Honda DTC Codes for P16D5 - Page 10.

