

## What Does The Hyundai B1474 Code Mean?

The SRSCM sets DTC B1474 if the measured resistance value of DCAB circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

## What Are The Potential Causes Of The Hyundai B1474 Code?

- Poor connection of connected part.
- Poor connection between shorting bar and release pin.
- Faulty CAB.
- Faulty SRSCM.

## **Reference Sources**

SRSCM (SRS Control Module) General Information for B1474 - Hyundai Genesis Coupe, pages 206-208.

