

## What Does The Infiniti C1120 Code Mean?

When the control unit detects a malfunction in the front LH inlet solenoid circuit.

## What Are The Potential Causes Of The Infiniti C1120 Code?

- Harness or connector
- ABS actuator and electric unit (control unit)
- Fusible link
- Battery power supply system

## **Reference Sources**

Brake Control System Repair Information for C1120 - 2008 Infiniti FX35/FX45, page 27.

