

JEEP U1437: INTAKE AIR TEMPERATURE FROM ECM - SIGNAL NOT AVAILABLE

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	Yes

What Does The Jeep U1437 Code Mean?

Treat this dtc as a implausible signal dtc when performing the communication diagnostic procedure.

Reference Sources

[Jeep U1437](#), DTCDECODE.