

MITSUBISHI B1486: PASSENGER SEAT BELT WARNING LIGHT DRIVE CIRCUIT SYSTEM FAULT 2

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$50-\$300
Can I Still Drive?	:	No

What Does The Mitsubishi B1486 Code Mean?

When a malfunction is detected in the output transistor inside the SRS-ECU. However, if the vehicle condition returns to normal, DTC B1486 will be automatically erased, and the passenger seat belt warning light will go out.

What Are The Potential Causes Of The Mitsubishi B1486 Code?

- Damaged wiring harnesses or connectors
- Malfunction of the SRS-ECU

Reference Sources

[Mitsubishi B1486](#), DTCDECODE.