

## What Does The Nissan P3004 Code Mean?

The inverter voltage does not rise during precharge (time from when SMRP turns on until when SMRG turns on).

## What Are The Potential Causes Of The Nissan P3004 Code?

- Inverter with converter assembly
- Frame wire
- HV battery assembly
- Wire harness or connector
- Hybrid battery junction block assembly

## **Reference Sources**

Nissan P3004, DTCDECODE.

