

What Does The P0000 Code Mean?

ISO/SAE Reserved codes are codes that have been set aside by the International Organization for Standardization (ISO) and the Society of Automotive Engineers (SAE) for future use. These codes are not currently assigned to any specific diagnostic trouble code (DTC) definition, but they may be used in the future as new codes are added to the system.

P0000 is one such code that falls under the ISO/SAE Reserved category and does not have a specific definition or meaning. However, it's worth noting that the meanings of diagnostic trouble codes can change over time as new technologies and systems are developed.

Find out more by reading our detailed explanation on [ISO/SAE Reserved codes](#).