

P024F: CHARGE AIR COOLER BYPASS POSITION SENSOR A CIRCUIT HIGH

OVERVIEW

Severity	:	Medium
DIY Difficulty Level	:	Intermediate
Repair Cost	:	\$50-\$100
Can I Still Drive?	:	No

What Does The P024F Code Mean?

In forced inducted systems, they use a Charge Air Cooler or what I am going to call it, an Intercooler (IC) to help in cooling the charge air the engine uses. These work similar to a radiator.

In the IC's case, instead of cooling antifreeze, it cools air to make for a more efficient air/fuel mixture in turn, better fuel mileage, better performance, etc. The IC is part of the charge pressure side of the induction system. The bypass valve is used just as the name implies, to let the air bypass the intercooler to be dumped into the atmosphere and/or recycled.

The Electronic Control Module (ECM) uses it to adjust valve according to current engine conditions and needs. The ECM also monitors the physical position of the valve by using a Charge Air Cooler Bypass Position Sensor.

The ECM illuminates the check engine light with P024F and associated codes when it monitors a condition outside of a specific range within the IC's Bypass Control circuit and/or within the sensors involved. This code may be caused by a mechanical and/or electrical fault. If i had to guess here, i would lean towards a mechanical problem more likely being the problem. That being said either are possible.

P024F Charge Air Cooler Bypass Position Sensor A Circuit High code is set when there is an abnormally high electrical value within the position sensor or its circuit.

What Are The Symptoms Of The P024F Code?

Symptoms of a P024F engine code may include:

- Poor engine performance
- Vehicle entering "limp mode"
- Engine misfiring
- Poor fuel mileage

What Are The Potential Causes Of The P024F Code?

Causes for this code may include:

- Stuck open/closed bypass valve
- Obstruction in bypass valve's operational range of motion
- Charge air cooler bypass position sensor defective
- Broken or damaged wiring harness
- Fuse/relay defective
- ECM issue
- Pin/connector problem. (e.g. corrosion, broken lock tab, etc.)

How Can You Fix The P024F Code?

Be sure to check for technical service bulletins (TSBs) for your vehicle. Getting access to a known fix can save you time and money during diagnosis.

Basic Step #1

Locate your charge air cooler bypass control valve by following the charge piping going to your intercooler (IC), it may be mounted directly to charge pipe.

Depending heavily on your particular make and model, you may find your IC mounted in your front bumper, front fenders or possibly directly under the hood among many other possible locations. Once valve is located, inspect for any obvious physical damage.

NOTE: Make sure engine is off.

Basic Step #2

It may be fairly simple to remove the valve completely from the vehicle to verify it's functionality. Especially recommended if code P024B is active. Once removed, inspect for any obstructions in the valve's range of motion. If possible, clean valve before reinstalling.

NOTE: Always refer to service manual first because this may not be possible or recommended for

that matter on your vehicle.

Basic Tip #3

The harness for the bypass valve may be routed through areas that are exposed to the elements. These areas should be inspected closely for nicks, cuts, signs of corrosion, etc. in the wires involved within the circuit.

NOTE: Make sure to disconnect battery before performing any electrical repairs.

Basic Step #4

Depending on your scan tool, you may be able to verify the valve's functionality by controlling it and observing its range of motion. If accessible you could disconnect one end of valve to gain sight of the moving parts. Using your scan tool, open valve completely and close while observing the mechanical operation of the valve itself.

If you notice the valve sticking and there is nothing obstructing it, more than likely, the valve is defective. In this case, you can try replacing it. Make sure the manufacturer also recommends a new valve in this case. Refer to manual.

The charge cooler bypass control sensor is typically located/mounted on the valve itself inline with the valve "door" in order to monitor position effectively. It is of high importance to make sure the "door" is free from obstruction throughout its range of motion.

Basic Step #5

You will want to rule out any electrical problem within the harness involved. To do this, you may have to disconnect it at the valve and the ECM. Using your multimeter, verify the integrity of the circuit by performing numerous basic electrical tests (e.g. continuity). If everything checks out, there may be some input tests you could do involving testing the connector at the valve to verify the ECM functionality with the valve.

Severity Description

Severity in this case would be moderate. You don't want to leave this issue unattended as it could develop into something much more serious fairly quickly. Keep in mind, problems don't get better over time unless rectified. Engine damage is expensive, almost every time so if you've exhausted your abilities, bring vehicle to a reputable repair facility.

Reference Sources

[P024F: Charge Air Cooler Bypass Position Sensor A Circuit High](#), OBD-Codes.