

## SAAB P1817: SPORT MODE MANUAL SWITCH CIRCUIT (MANUAL SWITCH)

### OVERVIEW

Severity	:	<div>High</div>
DIY Difficulty Level	:	<div>Intermediate</div>
Repair Cost	:	\$120-\$250
Can I Still Drive?	:	<b>Yes</b> (Short-term only)

### What Does The Saab P1817 Code Mean?

Input signal circuit of manual mode switch is open or shorted. Manual mode can not be set. When shifting to "N" , the SPORT shift indicator light illuminates.

### What Are The Potential Causes Of The Saab P1817 Code?

- Faulty select lever assembly
- Short circuit of harness between body integrated unit and manual mode
- Temporary poor contact of connector or harness may be the cause
- Faulty transmission module

### Reference Sources

[Technical Service Bulletin PIP5094 for P1817](#)