

SUBARU P1116: ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT LOW INPUT

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	Yes (Short-term only)

What Does The Subaru P1116 Code Mean?

Key on or engine running; and the TCM detected an unexpected "low" voltage condition on the Engine Torque Control signal circuit between the controllers.

How Can You Fix The Subaru P1116 Code?

- Check output signal from ECM
- Check harness between ECM and TCM connector

Reference Sources

[Subaru Impreza Repair Manual for P1116](#) - Pages 584-585.