

What Does The Toyota P1690 Code Mean?

Key on or engine running; and the PCM detected an unexpected voltage condition on the Oil Control Valve (OCV) circuit in the test.

What Are The Potential Causes Of The Toyota P1690 Code?

- OCV (valve) signal (+) or (-) circuit is open or shorted to ground
- OCV (valve) signal circuit is shorted to VREF or system power
- OCV (valve) is damaged or has failed
- PCM had failed

Reference Sources

Toyota P1690, DTCDECODE.

