

ACURA B1057: RELAY CONTROL MODULE LOST COMMUNICATION WITH MICU (DOORSW MESSAGE)

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	Yes (Short-term only)

What Does The Acura B1057 Code Mean?

This code indicates poor communication between the Relay Control Module and the MICU

Note: If DTCs [B1055](#), [B1056](#), [B1057](#), [B1157](#), [B1159](#), [B1180](#), [B1255](#), [B1955](#), [B2155](#), [B2156](#), and [B2161](#) are indicated, perform the MICU input test.

What Are The Potential Causes Of The Acura B1057 Code?

Below are some possible causes of this DTC:

- Loose or poor connections between the Relay Control Module and the driver's MICU
- Blown fuse in the main under-hood fuse box
- Blown fuse in the under-dash fuse/relay box
- "Open" or "Short" to ground at the Relay Control Module
- "Open" or "Short" to ground at driver's MICU
- Faulty Relau Control Module
- Faulty MICU

Reference Sources

[Acura B1057](#), DTCDECODE.