

ACURA B1062: RELAY CONTROL MODULE LOST COMMUNICATION WITH COMBINATION SWITCH CONTROL UNIT (HLSW MESSAGE)

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$75-\$200
Can I Still Drive?	:	Yes (Short-term only)

What Does The Acura B1062 Code Mean?

This code indicates poor communication between Relay Control Module and the Combination Switch Control unit.

What Are The Potential Causes Of The Acura B1062 Code?

Below are some possible causes of this DTC:

- Loose or poor connections between the Relay Control module and the Combination Switch Control unit
- Blown fuse in the main under-hood fuse box
- Blown fuse in the under-dash fuse/relay box
- "Open" or "Short" to ground at the Relay Control Module
- "Open" or "Short" to ground at Combination Switch Control unit
- Faulty Relay Control Module
- Faulty Combination Switch Control unit

Note: If DTCs [B1007](#), [B1062](#), [B1063](#), [B1155](#), [B1156](#), [B1957](#), [B1958](#), and [B2969](#) all indicated perform the combination switch control unit input test

Reference Sources

[Acura B1062](#), DTCDECODE.