

ACURA P1387: CAMSHAFT POSITION SENSOR 2 NO SIGNAL

OVERVIEW

Severity	:	<div><div>High</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$200-\$400
Can I Still Drive?	:	No

What Does The Acura P1387 Code Mean?

Engine cranking or running; and the PCM did not detect any signals from the Camshaft Position 2 (CMP) sensor during the CCM test.

Note: The engine will start and run without the CMP sensor signal.

What Are The Potential Causes Of The Acura P1387 Code?

- CMP2 signal circuit is open or shorted to ground
- CMP2 pickup unit is damaged or has failed
- CMP2 sensor is damaged or has failed
- PCM has failed

Reference Sources

[Acura P1387](#), DTCDECODE.