

DODGE B1C12: DRIVER ACTIVE HEADREST CONTROL CIRCUIT LOW

OVERVIEW

Severity	:	<div><div>Medium</div></div>
DIY Difficulty Level	:	<div><div>Intermediate</div></div>
Repair Cost	:	\$100-\$800
Can I Still Drive?	:	Yes (Short-term only)

What Does The Dodge B1C12 Code Mean?

The Occupant Restraint Controller (ORC) monitors the Driver Active Headrest during the start up phase of the ORC module. The Driver Active Headrest communication and on board diagnostics are powered by the ORC signal. This code will set, if the ORC detects low voltage on the (R676) Active Head Restraint 1st Row Driver Signal circuit.

What Are The Potential Causes Of The Dodge B1C12 Code?

- (R676) active head restraint 1st row driver signal circuit shorted to ground
- Driver active headrest
- Occupant restraint controller (ORC)

Reference Sources

[Dodge B1C12](#), DTCDECODE.